

Chevy Bowtie Size and Fitment Guide

Version: 2026 Printable Reference

1. Confirm year, trim, and platform before ordering.
2. Measure emblem width, height, and mount spacing.
3. Verify mount style: clip, stud, or adhesive.
4. Confirm front and rear bowtie sizes separately.
5. Dry-fit alignment before final adhesive pressure.

Common Platform Notes:

- GMT800 1999-2006: mixed mount styles.
- GMT900 2007-2013: clip-in front common.
- K2XX 2014-2018: clip plus adhesive combos.
- T1XX 2019+: trim-specific fitment variation.

More guides: <https://engravingnation.store/chevy-bowtie>